

Mac Mini Network Configuration

Mac Mini Network Configuration: Breaking Up Thunderbolt Bridge for Fine-Grained Control

When working with Mac Minis, particularly when using Thunderbolt for high-speed networking, you might run into limitations with macOS's default behavior of grouping all Thunderbolt ports under one Thunderbolt Bridge. By default, this setup combines all the Thunderbolt ports into a single network interface, which doesn't allow for individual point-to-point control of each Thunderbolt connection. In this post, we'll go through the steps to break up this Thunderbolt Bridge into three separate network services, each tied to a specific Thunderbolt port, enabling better control and flexibility for networking between nodes.

The goal is to bypass Thunderbolt PCI device-tree routing and instead create individual network services for each Thunderbolt port. This provides full control of point-to-point routing while maintaining the networking stack involved for communication. Here's how to set up a Mac Mini for neighbor-to-neighbor communication over Thunderbolt ports.

Step 1: Initial Network Configuration

Before any configuration, the network services should look something like this after a fresh macOS installation.

```
~ % networksetup -listallnetworkservices
An asterisk (*) denotes that a network service is disabled.
Ethernet
Thunderbolt Bridge
Wi-Fi
```


We need to get rid of the Thunderbolt Bridge service, as it will bridge all 3 thunderbolt ports into one network service, which we don't want. Instead, we are going to create three new networking services, one for each thunderbolt port named "thunderbolt1" "thunderbolt2" and "thunderbolt4". I am following the mac-mini device naming conventions from the settings app.

Step 2: Disable Thunderbolt Bridge

The first thing we need to do is disable the **Thunderbolt Bridge** service. This can be done via the following command:

```
~ % networksetup -setnetworkserviceenabled Thunderbolt\ Bridge
off
```


While this can be done through the Terminal, there are additional UI steps required to fully delete the Thunderbolt Bridge, particularly related to system permissions. This service, once disabled, will no longer bridge all ports into a single service.





The screenshot shows the 'Network' settings in the System Preferences application on macOS. The left sidebar lists various system preferences, with 'Network' selected and highlighted in blue. The main pane displays network configuration for the 'Thunderbolt Bridge' interface, which is currently using DHCP and has a self-assigned IP address of 169.254.57.252. Other details shown include Subnet mask (255.255.0.0), Router (Router), and DNS Servers (DNS Servers). At the bottom of the pane are two buttons: 'Delete Service...' and 'Make Inactive'. The 'Delete Service...' button is highlighted with a red rectangular border.


IPv4 Configured	Using DHCP
IP address	169.254.57.252
Subnet mask	255.255.0.0
Router	Router
DNS Servers	DNS Servers
Search Domains	Search Domains

Delete Service... **Make Inactive** ?









Step 3: Create New Network Services

Next, we need to create three separate network services for each of the Thunderbolt ports. This setup will allow us to treat each port independently, which is essential for point-to-point communication between nodes.

```
~ % networksetup -createnetworkservice "Thunderbolt 1" en2  
~ % networksetup -createnetworkservice "Thunderbolt 2" en3  
~ % networksetup -createnetworkservice "Thunderbolt 4" en4
```

In these commands:

- **en2, en3, and en4** correspond to the Thunderbolt interfaces on your Mac Mini.
- We name the services "Thunderbolt 1", "Thunderbolt 2", and "Thunderbolt 4", following the default macOS naming conventions for clarity.

Now, we need to configure the IP addresses that are present on each node. For convenience, and to keep all IPs on the direct-connections across the network

unique, IP addresses will be given out by NodId and PortId. NodId is a number from 1-256, and PortId is 10/20/30. Each node can only have three ports, so these are the only possible values on the network. Every node will be uniquely identified by the third byte of the ip address. This is a useful crutch for early forms of the neighbor discovery protocols, as we can use arping to get the ip/MAC addresses of the neighboring node and immediately know the host and port id.

Step 4: Configure IP Addresses

Now that we have separate network services for each Thunderbolt port, we need to configure them with unique IP addresses. This is important for ensuring each port communicates on its own distinct network. To achieve this, we use a structured IP addressing scheme based on NodId and PortId, where:

- **NodId** ranges from 1-256
- **PortId** can be 10, 20, or 30 (for Thunderbolt 1, 2, and 4, respectively)

For example, if NodId = 1, the IP addresses would be:

```
~ % networksetup -setmanual "Thunderbolt 1" 196.254.1.10  
255.255.0.0  
~ % networksetup -setmanual "Thunderbolt 2" 196.254.1.20  
255.255.0.0  
~ % networksetup -setmanual "Thunderbolt 4" 196.254.1.30  
255.255.0.0
```

These IP addresses will allow each port to communicate independently and maintain unique identifiers for each device on the network. The subnet mask **255.255.0.0** allows for sufficient addressing within this direct-connect setup.

Conclusion: Scaling and Further Use

With this configuration, you now have individual control over each Thunderbolt port, enabling direct point-to-point communication between your Mac Minis. This setup provides a robust foundation for building custom networking solutions, especially useful in environments where high-speed communication over Thunderbolt is necessary (e.g., data centers, high-performance computing clusters).

For those who want to scale this setup, consider automating the configuration with a script, or setting up a system where devices can dynamically discover and configure connections using protocols like mDNS or more sophisticated neighbor discovery protocols.

As with any network setup, testing is key, so ensure all configurations are correct, and monitor the system for optimal performance. Troubleshooting steps like using **ping**, **arping**, or reviewing **syslog** can help in quickly identifying and resolving

issues.

Thunderbolt networking gotcha's

Now that the Mac mini's thunderbolt bridge has been broken up into three network interfaces, it is up to us to bring up a link. An emulated link relies on a UDP connection to its neighbor, as building on top of UDP provides a datagram based abstraction of a link that's easier to work with than ethernet frames. A UDP connection requires a "server" side to bind to an IP/Port to serve requests on, and a "client" side that sends datagrams to the server. The server side simply sends frames out to the IP which sent a packet to the port. Since the thunderbolt ports are on separate network services with their own IP, different threads listening on the same port but different addresses will only receive messages from their respective links. This leaves only one problem, the client side needs to know the IP of the server on the other side to establish a connection.

To get info of a network service named "Thunderbolt 2"

```
~ % networksetup -getinfo Thunderbolt\ 2
```

Manual Configuration

IP address: 169.254.1.20

Subnet mask: 255.255.0.0

Router: (null)

IPv6: Automatic

IPv6 IP address: none

IPv6 Router: none

Ethernet Address: 36:0a:57:3b:c0:84

Flush ARP Cache

```
~ % sudo arp -a -d
```

Ethernet hardware ports marked with their interface names

